


POLESAVER™-PF



Before you embark on your post frame building journey, there's something crucial to consider: the foundation. Like any great endeavor, construction starts from the ground up, and having a solid foundation is paramount. Traditional methods often involve direct wood-to-ground contact, a technique that has stood the test of time but is not without its challenges, particularly when it comes to rot.

Enter Polesaver-PF, the ultimate solution for post frame buildings. This revolutionary product is designed to protect the critical ground-line section of your poles, ensuring a sturdy foundation for years to come. With a 40-year rot prevention guarantee, Polesaver-PF is not just a promise; it's peace of mind.

A vertical diagram showing a wooden post being installed in the ground. The post is partially buried in brown soil. A black rectangular sleeve, labeled "POLESAVER - PF", is shown being applied to the ground-line section of the post. The sleeve has a dashed line indicating the "Ideal Ground Line - Protection for Penetration - Lines the Trench Wall". Arrows point to the "TOP OF POST" and "HAUT DU POTEAU". The sleeve is labeled with "POLESAVER - PF", "POST FRAME PROTECTION", "PATENTED", and "DUAL-LAYER TECHNOLOGY".

DUAL-LAYER ROT SHIELD TECHNOLOGY

40 YEAR GUARANTEE

PROVEN IN VOLUME USE & INDEPENDENTLY TESTED

POLESAVER - PF

POST FRAME PROTECTION

PATENTED

DUAL-LAYER TECHNOLOGY

TOP OF POST
HAUT DU POTEAU

READILY AVAILABLE

QUICK AND EASY TO APPLY ON SITE

CAN BE APPLIED TO SUIT ANY BURIAL DEPTH

POLESAVER™-PF



ITEM #	TO FIT ROUND (POLE DIAMETER)	TO FIT SQUARE POLE SIZES	TO FIT RECTANGULAR POLE SIZES	SLEEVE WEIGHT / LB.	PCS/BOX	LB/BOX
PSPF15	6"	3 - 1/2" x 3 - 1/2" 4" x 4" 4 - 1/2" x 4 - 1/2" 5" x 5"	4 - 1/2" x 5 - 1/4" 5" x 4" 5 - 1/2" x 4 - 1/2"	0.66	50	37.5
PSPF20	8"	5 - 1/2" x 5 - 1/2" 6" x 6"	5 - 1/2" x 5 - 1/4" 5 - 1/2" x 7"	0.86	50	47.4
PSPF25	10"	7" x 7" 8" x 8"	6 - 3/4" x 7 - 1/2" 8 - 3/4" x 7 - 1/2"	1.05	50	56.7
PSPF30	12"	8 - 1/2" x 8 - 1/2" 9" x 9"	8 - 3/4" x 9" 8 - 3/4" x 10 - 1/2"	1.22	50	65.5

ITEM #	DESCRIPTION	ROLLS/CTN	LB/ROLL
PSPT	PoleSaver-PF Patch Repair Tape	4	2.2

SIMPLE INSTALLATION



1 Position the wrap around the post so that 4" - 5" is left above ground.



2 Remove the release paper from the adhesive strip and press the tape down firmly from the center to the edges.



3 Heat shrink the wrap to the post using a blow torch. Move the heat source from end to end, and ensure the wrap shrinks before moving on to the next section.



4 Whilst still hot, roll the wrap flat to the post to ensure a good seal.

POLESAVER-PF

Test Data, Standards, Accreditations & Approvals

Complies with requirements of A.W.P.A. Standard P20-18, BP-. (American Wood Protection Association)
ALL BARRIER PROTECTION SYSTEMS

Tested to A.W.P.A. E1-97:2005 (American Wood Protection Association):

2005. 'Standard method for laboratory evaluation to determine resistance to subterranean termites'

